
Thermal/Acoustic Insulation

Test Method Development

Small Tube Configuration



Initial Intermediate Scale Test Configuration



- BETWEEN FRAME BLANKET
- OVER FRAME BLANKET


EFFECT OF PRE-HEATING FILM




Initial Intermediate Scale Test Configuration




COMPARTMENTALIZED TEST



Intermediate Scale Flame Propagation Test Arrangement in 707



Intermediate Scale Flame Propagation Tests in 707 Overhead




Camera

Metallized PET (2072K)




Class 1 PET






Intermediate Scale Flame Propagation Test Arrangement



Over Frame Blanket

Between Frame Blanket


Metallized PET (2072K)



Metallized PET (2072K)




Polyimide Film



Polyimide Film, Post Test Damage



Energy Release Rate Determination




• Thermocouple Location


Energy Release Rate determined by:

Average of two thermocouples at each end, then the sum of the two end averages.


$$ERR=(T1+T2)/2 + (T3+T4)/2$$

If the mass flow rates are equal at both ends, then this procedure gives an approximation to the Energy Release Rate.






Radiant Panel Test Results: Percentage of Sample Burned




Full Scale Flame Propagation Tests in DC-10 Overhead



Gas Sampling

Calorimeter

Full Scale Flame Propagation Test Arrangement in DC-10




Between Frame Blanket

Over Frame Blanket

Class 1 PET-F




TWIN-JET UPPER DECK SIDEWALL INSULATION INSTALLATION




Class 1 PET-F, Thermocouple Installation



Class 1 PET-O, Arrangement of Ducts



Class 1PET-O, Flame Propagation on Duct




Class 1 PET-O, Flame Propagation on Duct



Class 1 PET-F, Arrangement of Ducts




Class 1 PET-O, Post Test Damage



Metallized PET (2072L)



Metallized PET, Propagation Along Ducts



Metallized PET (2072L), Small Ignition Source



Metallized PET (2072L), Post Test Damage



Metallized PET (2072L), Post Test Damage



Metallized PET (2072L), Post Test Damage




Metallized PVF-O



Metallized PVF-O, Propagation Along Ducts



Metallized PVF-O, Propagation Along Ducts




Metallized PVF-O, Post Test Damage



Metallized PVF-O, Post Test Damage



Energy Release Rate Determination




• Thermocouple Location

Energy Release Rate determined by:


Average of two thermocouples at each end, then the sum of the two end averages.

$$ERR = (A2+A3)/2 + (K2 + K3)/2$$

If the mass flow rates are equal at both ends, then this procedure gives an approximation to the Energy Release Rate.



OSU Test Results, Heat Flux = 1.77 W/cm²




TUBULAR BLANKET TEST ARRANGEMENT




ROLLED INSULATION TEST







INSULATION TUBE TEST




EFFECT OF PRE-HEATING FILM









FULL-SCALE TEST RIG




Aluminum Skin Testing





Second Generation Curved Test Rig



All Material 0.125-inch Thickness Except Center Vertical Former, 0.1875-inch Thick







Park Model DPL 3400 (609) 344-7709 Burner Type

Monarch Manufacturing Co., Inc * 80 PLP (Semi-Solid)

Nozzle Type

Nozzle Type (alt)

Hago Manufacturing Co., Inc * 80°S.S. (Semi-Solid)

(908) 232-8687

Thermocouples


Thermo Electric Co., Inc * Type K Grounded, 1/8"

Ceramic Packed, Metal Sheathed (201) 843-5800

Omega Engineering, Inc * Air Velocity Meter 1-800-848-4286 Model HH30A

Heat Flux Transducer Vatell Corporation * Model 1000 Series

(540) 961-2001



Burner Calibration Requirements

Fuel Flowrate: 6 gal/hr

Air Velocity: 2200 ft/min

Temperature: 2100 ± 100°F

Heat Flux: 13.5 ± 0.5 Btu/ft-sec

* website available

Typical Calibration Rig



Proposed Burnthrough Test Standard

